




Grease and adhesive application points



REMOVAL SERVICE POINT

◀A▶ CAMSHAFT SPROCKET REMOVAL



INSTALLATION SERVICE POINTS

▶A◀ CAMSHAFT INSTALLATION

- (1) Apply engine oil to the cams and journals of the camshaft.
- (2) Mount the camshaft on the cylinder head.

Caution

Make sure that the camshaft has a unique orientation for installation, the intake side and exhaust side. The exhaust camshaft has a slit in the rear end face.